

RPS HAWK 250、HAWK-X PARTS CATALOGUE




车架FRAME





发动机总成 ENGINE COMP

1, 发动机总成 Engine comp



2, 尾盖 Tail cover

3, 变档杆 Gearshift lever

4, 发动机上悬挂, 2件 Engine top suspension 2pcs

5, 发动机前悬挂, 2件 Engine front suspension 2pcs

6, 发动机后悬挂 Engine rear suspension

7, 发动机下悬挂螺栓及紧固螺母3件 Engine bottom suspension bolt and nut, 3sets

8, 尾盖紧固螺栓2件 Tail cover bolt 2pcs

9, 上悬挂紧固螺栓3件, 紧固螺母3件
Top suspension bolt and nut, 3sets


10, 前悬挂紧固螺栓3件, 紧固螺母3件
Front suspension bolt and nut, 3sets

11, 后悬挂与车架紧固螺栓2件
Bolt, 2sets for rear suspension and frame



消声器总成 MUFFLER

1, 消声器筒体 Muffler pipe



2, 消声器前段 Front part, muffler

3, 消声器前段与后段连接抱箍

Hold hoop, muffler front part and rear part

4, 连接抱箍紧固螺栓

Bolt, hold hoop.

5, 消声器前段隔热防烫板

Insulating panel, muffler front part

6, 防烫板紧固螺栓2件, 弹簧垫圈2件, 平垫圈2件

Bolt 2pcs, spring washer 2pcs, plate washer 2pcs

7, 消声器与发动机紧固螺母2件

Nut 2pcs, muffler and engine

8, 消声器筒体防烫装饰板

Insulating panel, muffler rear part

9, 防烫装饰板与筒体紧固螺栓3件, 平垫圈3件, 胶圈3件

Bolt 3pcs, plate washer 3pcs, rubber ring 3pcs for insulating panel and muffler rear part

10, 消声器与车架连接螺栓1件

Bolt 1pcs, muffler and frame

11, 平垫圈1件

Plate washer 1pcs

12, 消声器与车架连接螺栓1件, 螺母1件

Bolt 1pcs, nut 1pcs, for muffler and frame





1, 前轮胎 Front tire

2, 前轮毂 Front rim

3, 前碟刹盘 Front brake disc

4, 前轮轴 Frong wheel axle

5, 计速器 Speed Sensor

6, 前轮轴紧固螺母 Nut, front wheel axle

7, 前轮左衬套 Left bush, front wheel

8, 止退片2件 Stabler, brake disc bolt

9, 碟刹盘与前轮连接螺栓4件
Bolt 4pcs, brake disc and front wheel





后轮总成 REAR WHEEL

1, 后轮胎 Rear tire

2, 后轮毂 Rear rim

3, 链盘 Sprocket

4, 后碟刹盘 Rear brake disc

5, 链盘与轮毂连接螺栓及螺母 4套,
Bolt and nut 4sets, sprocket and rear rim


6, 后碟刹钳与平叉定位板
Position plate, rear disc calliper and rear fork

7, 后轮轴
Rear wheel axle

8, 后轮左衬套
Left bush, rear wheel

9, 链条调节器挡板2件
Block 2pcs, chain adjuster

10, 后轮轴紧固螺母
Nut, rear wheel



前减震器 FRONT SHOCK

1, 前右减震器 Right, front shock

2, 前左减震器 Left, front shock

3, 里程线夹 Clamp, mileage cable


4, 碟刹油管线夹 Clamp, front brake oil line

5, 线夹紧固螺栓4件, 平垫圈4件
Bolt and plate washer 4set, for clamp

6, 反射器与方向柱连接支架2件
Bracket 2pcs, for reflector and steering stem

7, 反射器2件
Reflector 2pcs





后减震 REAR SHOCK


1, 后减震器 Rear shock

2, 后减震器与车架连接螺栓
Bolt, rear shock and frame

3, 紧固螺母
Nut

4, 后减震器与平叉连接螺栓1件
Bolt 1pcs, rear shock and

5, 紧固螺母
Nut




平叉 REAR FORK

- 1, 平叉 Rear fork
- 2, 链条调节器 Chain adjuster
- 3, 平叉轴 Fork axle
- 4, 平叉管防尘盖2件 Dust cap 2pcs, rear fork
- 5, 平叉轴紧固螺母 Nut, rear fork axle



燃油箱总成 GAS TANK COMF



1, 燃油箱体 Gas tank

2, 燃油箱锁盖 Gas cap with key

3, 油位传感器 Gas tank sensor

4, 油开关 Gas tank cock

5, 油箱与车架连接胶垫 Rubber washer, gas tank and frame

6, 油箱与车架连接紧固螺栓1件, 平垫圈1件
Nut and plate washer 1set, gas tank and frame

7, 油位传感器与油箱紧固螺母4件 Nut 4pcs, gas tank sensor and gas tank


8, 油箱与左、右覆盖件连接“工”字胶2件 Rubber washer 2pcs, gas tank and left&right body cover

9, 油箱与车架固定胶塞2件


Rubber block 2pcs, gas tank and frame



方向柱总成 STEERING STEM



- 1, 方向柱 Steering stem
- 2, 方向柱下轴承 Lower bearing, steering stem
- 3, 方向柱上轴承 Upper bearing, steering stem
- 4, 轴承上座圈 Upper ring, bearing
- 5, 方向柱紧固平垫圈 Plate washer, steering stem
- 6, 方向柱紧固螺母 Nut, steering stem




蓄电池 BATTERY

1, 蓄电池（电瓶）Battery

2, 随车工具箱 Tool kit box(cancelled)


3, 电瓶固定胶带(Strap, battery)

4, 工具箱与车架连接固定螺栓2件，平垫圈2件
Bolt and plate washer 2sets, tool kit box and frame(cancelled)



链条、电瓶支架 CHAIN,BATTERY BRACKET

1, 链条 Chain



2, 链盒 Chain box

3, 链条护卡 Chain protection

4, 链条护卡与平叉连接紧固螺栓1件, 平垫圈1件
Bolt and plate washer 1set, chain protection and rear fork


5, 链条下护板
Lower protective plate, chain

6, 链盒与平叉连接紧固螺栓2件, 平垫圈2件
bolt and plate washer 2set, chain box and rear fork


7, 电瓶支架
Battery bracket

8, 链条下护板与平叉连接紧固螺栓2件
Bolt 2pcs, chain lower protective plate and rear

9, 电瓶支架与车架连接紧固螺栓3件
Bolt 3pcs, battery bracket and frame.



座垫 SEAT



1, 座垫 Seat

2, 座垫与车架连接紧固螺栓2件
Bolt 2pcs, seat and frame


3, 平垫圈2件
Plate washer 2pcs



手把管总成 **HANDLE BAR COMP**

1, 手把管 Handle bar

2, 左手把胶 Left handle grip



3, 防撞棒 Anti dumper

4, 离合手柄 Clutch lever

5, 离合手柄与手把管连接紧固螺栓2件

Bolt 2pcs, clutch lever and handle bar

6, 闸把 Handle bar switch


7, 油门拉索 Throttle cable

8, 离合拉索 Clutch cable

9, 右手把胶（加油器）Right handle bar grip
(accelerator is included)


10, 熄火开关 Kill switch

11, 油门拉索座 Throttle cable housing




上连板 **UPPER CONNECTING PLATE**

1, 上连板 Upper connecting plate



- 2, 手把管与上连板紧固螺栓4件
Bolt 4pcs, handle bar and upper connecting plate
- 3, 平垫圈
Plate washer
- 4, 方向柱与上连板连接紧固螺母
Nut, steering stem and upper connecting plate
- 5, 方向柱防尘胶塞
Rubber dust block, steering stem

15



大灯、脚蹬、后视镜 HEADLIGHT, FOOT REST, MIRROR

- 1, 前大灯 Head light
- 2, 前面罩 Head light cover
- 3, 左后视镜 L mirror



4, 右后视镜 R mirror

5, 右脚蹬 R foot rest

6, 左脚蹬 L foot rest

7, 脚蹬与车架连接紧固螺栓4件

Bolt 4pcs, foot rest and frame

8, 前面罩与方向柱连接紧固螺栓2件


Bolt 2pcs, head light cover and steering stem

9, 前大灯与方向柱连接胶套2件

Rubber sleeve 2pcs, head light and steering stem

10, 面罩与大灯连接紧固自攻钉4件, 平垫圈4件

Screw and plate washer 4sets, head light cover and head light.




16

前碟刹总成 FRONT BRAKE COMP

1, 前碟刹钳 Front brake calliper

2, 前碟刹泵紧固螺栓2件 Bolt 2pcs, front brake pump



3, 前碟刹油杯 Oil box, front brake


4, 前碟刹手柄 Front brake lever

5, 前碟刹油管 Front brake oil line



前挡泥板、侧支架、主搁脚
FRONT FENDER, SIDE STAND, MAIN STAND

1, 前挡泥板 Front fender



2, 侧支架 Side stand

3, 左、右搁脚 L&R foot rest

4, 前挡泥与方向柱连接紧固螺栓4件, 平垫圈4件
Bolt and plate washer 4sets, for front fender and steering stem

5, 侧支架与车架连接螺栓1件, 螺母1件
Bolt and nut 1set, for side stand and frame

6, 侧支架回位弹簧
Spring, side stand

18


后挡泥总成 REAR FENDER COMP



1, 后挡泥板 Rear fender

2, 尾灯 Tail light

3, 牌照灯总成 Licence plate light



4, 后牌照支架 Licence plate bracket


5, 后牌照支架与后挡泥连接螺栓,平垫, 螺母2套
Bolt,plate washer, nut 2sets, licence plate bracket and rear fender

6, 尾灯与后挡泥连接螺母2件, 平垫圈2件
Nut and plate washer 2sets, tail light and rear fender

7, 牌照灯与后挡泥连接自攻钉3件, 平垫圈3件
Screw and plate washer 3 sets, licence plate light and rear fender

8, 后挡泥与车架连接紧固螺栓2件, 平垫圈2件
胶平垫2件

Bolt, plate washer and rubber plate washer 2 sets, rear fender and frame



后扶手, 后转向灯

REAR ARMREST

1, 左后扶手 Left rear armrest

2, 右后扶手 Right rear armrest



3, 后扶手与车架连接紧固螺栓2件
Bolt 2pcs, rear armrest and frame

4, 后扶手与车架连接紧固螺栓, 工字胶, 螺母2件,
Bolt, rubber, nut 2sets, rear armrest and frame

5, 后左转向灯 Rear left turn light

6, 转向灯与后扶手连接支架2件
Bracket 2pcs, rear turn light and rear armrest

7, 转向灯与后扶手连接紧固螺栓2件
Bolt 2pcs, turn light and rear armrest


8, 后右转向灯
Rear right turn light



空滤器 AIR FILTER

1, 空滤器 Air fliter

2, 空滤器与化油器连接抱箍



Clamp, air fliter and carburetor


3, 头盔锁

Lock

4, 头盔锁与车架连接紧固螺栓2件

Bolt 2pcs, lock and frame

21




后碟刹总成 REAR DISC BRAKE COMP

1, 后碟刹钳 Rear brake caliper

2, 后碟刹钳与平叉连接定拉板紧固螺栓2件
Bolt 2pcs, rear brake caliper and rear fork

3, 后碟刹油杯
Rear brake oil box




- 4, 后碟刹油杯与车架连接紧固螺栓
Bolt, rear brake oil box and frame
- 5, 后碟刹总成与车架连接紧固螺栓2件, 螺母2件
Bolt and nut 2sets, rear brake comp and frame
- 6, 后制动踏板回位弹簧
Spring, rear brake pedal
- 7, 后碟刹车灯开关弹簧
Switch spring, rear brake light
- 8, 后制动踏板
Rear brake pedal
- 9, 后制动踏板与车架连接平垫圈
Plate washer, rear brake pedal and frame
- 10, 开口销
Cotter pin
- 11, 后碟刹总成
Rear brake comp
- 12, 后碟刹油管与平叉固定支架2件
Bracket 2pcs, rear brake oil line and rear fork
- 13, 后碟刹油管与平叉连接紧固螺栓2件
Bolt 2pcs, rear brake oil line and rear fork
- 14, 后碟刹油管
Rear brake oil line



化油器总成 CARBURETOR

- 1, 化油器总成 Carburetor
- 2, 进气管 Air intake




- 3, 进气管与发动机连接紧固螺栓2件
Bolt 2pcs, air intake and engine
- 4, 点火线圈线夹
Clamp, ignition coil
- 5, 进气管与化油器连接紧固螺母2件
Nut 2pcs, air intake and carburetor




尾框、起动杆 TAIL COVER, KICK LEVER


- 1, 尾框架 Bracket, tail cover
- 2, 座垫挂钩 Hook, seat
- 3, 座垫挂钩与车架连接紧固螺栓2件
Bolt 2pcs, seat hook and frame



- 4, 尾框与车架连接螺栓装饰胶塞2件
Rubber block 2pcs, tail cover and frame bolt
- 5, 尾框与车架连接紧固螺栓4件
Bolt 4pcs, tail cover and frame
- 6, 平垫圈4件
Plate washer 4pcs
- 7, 起动杆
Kick lever



- 仪表、点火锁、前转向灯**
METER, IGNITION LOCK, FRONT TURN LIGHT
- 1, 仪表
Meter
- 2, 里程线
Mailage cable
- 3, 方向锁
Steering lock
- 4, 方向锁盖



Steering lock cap

5, 方向锁与方向柱连接紧固螺栓2件

Bolt 2pcs, steering lock and steering stem

6, 方向锁盖与上连板连接紧固螺栓2件

Bolt 2pcs, steering lock cap and top connecting plate

7, 仪表与仪表支架连接紧固螺母3件

Nut 3pcs, meter and meter bracket

8, 仪表支架

Meter bracket

9, 仪表与仪表支架连接“工”字胶3件

Rubber parts 3pcs, meter and meter bracket

10, 仪表支架与上连板连接紧固螺栓2件

Bolt 2pcs, meter bracket and top connecting plate

11, 前左转向灯

Front left turn light

12, 前右转向灯

Front right turn light

13, 转向灯支架


Bracket, turn light

14, 转向灯与支架连接紧固螺母2件

Nut 2pcs, turn light and bracket

15, 转向灯支架与上连板连接紧固螺栓2件

Bolt 2pcs, turn light bracket and top connecting plate



油箱左、右覆盖件

LEFT&RIGHT COVER, GAS TANK


1, 油箱右覆盖件

Right cover, gas tank

2, 油箱左覆盖件

Left cover, gas tank

3, 油箱覆盖件支架



Gas tank cover bracket

4, 油箱覆盖件与支架连接螺栓2件, 平垫圈2件, 紧固螺母2件

Bolt, plate washer and nut 2sets, gas tank cover and bracket

5, 油箱覆盖件与油箱连接紧固螺栓2件, 平垫圈2件, 胶平垫2件

Bolt, plate washer and rubber washer 2sets, gas tank cover and gas tank

6, 油箱覆盖件支架与车架连接紧固螺栓1件, 平垫圈1件

Bolt and plate washer 1pcs, gas tank cover bracket and frame



主线、电器件 **CABLE HARNESS, ELECTRIC PARTS**


1, 主线缆

Cable harness

2, 制动灯开关线

Brake light switch

3, 调压器



Regulator

4, 调压器与车架紧固螺栓

Bolt, regulator and frame

5, 点火线圈与车架紧固螺栓2件

Bolt 2pcs, ignition coil and frame

6, 点火线圈

Ignition coil

7, 继电器

Starting relay

8, 闪光器

Flasher

9, 点火器

CDI

10, 喇叭

Horn

11, 喇叭与车架固定螺栓

Bolt, horn and frame




左、右侧盖

LEFT&RIGHT SIDE COVER

1. Right side cover

2. Left side cover

3. Rubber plate washer 2pcs



1. 右侧盖
2. 左侧盖
3. 胶平垫2件
4. 平垫圈2件
5. 侧盖与车架连接紧固螺钉2件

4. Plate washer 2pcs
5. Screw 2pcs, side cover and frame

-28-